

00010010100001001000000100101010 001010101101100  
00101010101110010101011011000 00111010001010  
011101000101000010010100001001010101010

**THE FUTURE  
OF KEYLESS  
ACCESS HAS  
ARRIVED.**

Learn more about our full line of garage door openers and our exclusive accessories—such as our Premium Remote Control and Smart Control Panel™.

[www.liftmaster.com](http://www.liftmaster.com)

CHAMBERLAIN®  
**LiftMaster**®

The Chamberlain Group, Inc. • 845 Larch Avenue • Elmhurst, IL 60126

©2007 LM 379 • The Chamberlain Group, Inc. • Printed in the U.S.A. • 07/07  
LMCA0379

CHAMBERLAIN®  
**LiftMaster**®

# NEW FINGERPRINT KEYLESS ENTRY FROM LIFTMASTER®.

Nearly **half** of U.S. homeowners with an automatic garage door opener own a **keyless entry system**.


More than **75%** of these owners cite **convenience as the #1 benefit** – nothing extra to carry, no lost keys, and now no codes to remember. Home access is effortless.

**Fingerprint sensor technology makes access to your garage quick, safe and secure.**

**Recognizes up to four unique fingerprints** – Only the registered users can gain entry to your garage, guaranteeing secure access.

**Easy to use** – Simply slide open the protective cover to turn the device on, swipe your finger and your garage door will open.

**No passcodes or PIN number to remember** – Access cannot be copied or passed on to others.



CHAMBERLAIN®

# LiftMaster®



*Great for families and senior citizens*

**Uses Security+® with rolling code technology.** Entry pad transmits a new code with every use.

**Easy to install** – Two screws, no wires.

**Wireless, battery-operated** – powered by four AAA batteries (included).

**Weatherproof** slide-up protective cover.

**No need to replace existing keyless entry.** Works in conjunction with LiftMaster model 377LM keyless entry, still allowing temporary access via four-digit code.

**315MHz compatible**

**Programs in four easy steps**

Setting up users is incredibly simple:

- 1 Push and hold the "Enroll" button (blue) for one second. "Enroll" light (yellow) and "Ready" light (green) will turn on.
- 2 Slide your finger down across the finger sensor. "Pass" light (green) will flash once.
- 3 Repeat this step two more times. The "Enroll" light (yellow) and the "Pass" light (green) will flash three times.
- 4 Your unique fingerprint has now been securely enrolled in the system.

